



## 12104FLT FLOWTECH I® STANDARD HEADERS 32104FLT FLOWTECH II® CERAMIC HEADERS

FORD MUSTANG 5.0L 1979-1993 (302W)  
MERCURY CAPRI 5.0L 1979-1986 (260-302W)

**WARNING! Breaking in an engine with ceramic-coated headers WILL result in damage to the coating and will VOID all warranties.** Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. FLOWTECH® recommends using cast iron exhaust manifolds or old headers to break in new engines to avoid coating damage. Please call tech service at 270-781-9741 for additional information regarding ceramic-coated exhaust products.

We realize that you had many choices when you chose your headers, and we thank you for choosing ours. At FLOWTECH® we put many years of performance exhaust experience into every product we build. We feel and know you will agree that FLOWTECH® Headers are the best you can buy at any price.

As a result of the restricted room available in some engine compartments, you may experience a close fit to some body and chassis components. This is a normal condition. If this is your first time installing a set of headers, it may be time consuming. While not complex, stick with it. As soon as you start your engine, the reward of additional horsepower and performance will be well worth your efforts. Proper installation and periodic maintenance will result in maximum performance and life from your FLOWTECH® Headers.

### **READ THESE INSTRUCTIONS CAREFULLY BEFORE STARTING:**

For ease of installation, your vehicle must be raised a minimum of 36". **Warning:** should you decide to install any exhaust product yourself, be warned that the original equipment jack that came with the vehicle is intended for emergency use only. The use of a frame jack in conjunction with a floor jack as the main support is highly recommended to minimize the accidental dropping of a vehicle while the installation proceeds. Never go under any vehicle that is supported by a bumper jack!

**INSTALLATION NOTES:** These headers are a multi-piece design. They were designed for easier installation. The header flange is cut only  $\frac{3}{4}$  of the way through. It is necessary that the flange be cut the remainder of the way through before installation. This may be done with a hacksaw. We have left the pieces together at the factory in order to prevent damage or loss during shipping.

### **PREPARE THE VEHICLE FOR INSTALLATION:**

1. Disconnect the battery to prevent accidental damage to the electrical system
2. Remove the stock exhaust manifold and stock headpipe.
3. Disconnect the water temperature sending unit.
4. Remove the oil dipstick tube and the spark plugs.

**CHECK CONDITION OF ENGINE MOUNTS :** It is recommended that new engine mounts be installed before installing headers.

### **LEFT SIDE HEADER INSTALLATION:**

1. Starting from below, work the header into position over the exhaust ports. Do not start the bolts.
2. Place the gasket in place and start all bolts. Install the L-4 slip tube and start all bolts.
3. Tighten all bolts progressively and evenly until they are tight.

### **RIGHT SIDE HEADER INSTALLATION:**

1. Work tube R-4 into position in front on the starter, do not start bolts yet.
2. Install tube R-3 on the outside of tube R-4, keeping it away from the starter. Do not start bolts yet.
3. Hold tube R-4 in position at the exhaust port. Tighten the starter cable with it positioned for maximum clearance.
4. Position the main body of the header from below, up over the top of the starter. Insert tubes R-3 and R-4 into the slip joints.
5. Position the header gasket in place and start all bolts. Install R-2 slip tube and start bolts. Tighten all bolts progressively and evenly until they are tight.

**AFTER HEADERS ARE IN PLACE:**

1. Inspect all points with limited clearance. Relocate any points that have direct contact with the header. Make sure there is adequate clearance around all lines (transmission, brake, fuel, and electrical wires). Reroute, as necessary. **Before installing your exhaust system, replace any fluids that you might have removed or lost.**
2. Reinstall the battery cable oil dipstick tube, and spark plugs.
3. To hook up your exhaust system, bolt a reducer and gasket into position behind each header collector. The left side reducer will need trimming due to the tight clearance to the transmission crossmember.

When you have finished installing your headers, take the vehicle for a road test. Listen carefully for any exhaust leaks or other strange noises and make corrections. When the vehicle has been driven for a few days, retighten the header bolts. We find that periodically checking the bolts will prevent the flange from warping and the burning out of the header gaskets.

**TECHNICAL SUPPORT**

**PHONE: 270-781-9741 • FAX: 270-781-9772**

**For online help, please check the Tech Service section of our website: [www.holley.com](http://www.holley.com)**

**LIMITATION OF LIABILITY - DISCLAIMER:** THE REGULATION OF EMISSIONS PRODUCTION, NOISE LEVELS, AND SAFETY STANDARDS IS UNDERTAKEN BY THE FEDERAL GOVERNMENT, EACH OF THE FIFTY STATE LEGISLATURES AND BY MANY LOCAL MUNICIPALITIES, TOWNS, AND COUNTIES.

*FLOWTECH®* MAKES NO WARRANTIES OF MERCHANTABILITY, OF FITNESS FOR PARTICULAR PURPOSE, OR THAT ITS PRODUCTS ARE APPROVED FOR GENERAL USE, OR THAT IT'S PRODUCTS COMPLY WITH LAWS, REGULATIONS, OR ORDINANCES IN THE STATES WHERE THEY MAY BE SOLD TO THE ULTIMATE PURCHASER, THE CONSUMER.

UNLESS EXPRESSLY STATED TO THE CONTRARY IN THE ACCOMPANYING CATALOG, INSTRUCTION SHEET, OR PRICE LIST, THE ENTIRE RISK AS TO THE CONFORMITY OF ANY COMPANY PRODUCT IN ANY SUCH STATE AND AS TO REPAIR SHOULD THE PRODUCT PROVE TO BE DEFECTIVE OR NONCONFORMING, IS ON THE RETAIL PURCHASER, THE BUYER, THE ULTIMATE CONSUMER, OF SUCH PRODUCT AND IT IS NOT UPON THE SELLER, DISTRIBUTOR, OR MANUFACTURER.

IN THE CONNECTION, RETAIL PURCHASER, THE BUYER, THE ULTIMATE CONSUMER ASSUMES THE BURDEN OF THE ENTIRE COST OF ANY AND ALL NECESSARY SERVICE, ALTERATIONS, OR REPAIR.

**THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.**

CALIFORNIA VEHICLE CODE, SECTIONS 27156 AND 38391, PROHIBITS THE ADVERTISING, OFFERING FOR SALE, OR INSTALLATION OF ANY DEVICE WHICH MODIFIES A VEHICLE'S EMISSIONS CONTROL SYSTEM UNLESS EXEMPTED. UNLESS OTHERWISE NOTED, *FLOWTECH®* HEADERS HAVE NOT RECEIVED AN EXEMPTION FROM THESE CODE SECTIONS AND ARE NOT LEGAL FOR SALE OR USE IN CALIFORNIA ON VEHICLES ORIGINALLY EQUIPPED WITH CATALYTIC CONVERTERS. IT IS ILLEGAL, EXCEPT FOR RACING VEHICLES, WHICH MAY NEVER BE DRIVEN UPON A HIGHWAY, TO REMOVE OR OTHERWISE RENDER INOPERATIVE ANY EMISSION CONTROL DEVICE ON REGULATED MOTOR VEHICLES (CHECK CATALOG LISTINGS TO ENSURE PROPER APPLICATION). IN THE OTHER 49 STATES, UNLESS OTHERWISE NOTED, *FLOWTECH®* HEADERS ARE NOT LEGAL FOR POLLUTION-CONTROLLED MOTOR VEHICLES, EXCEPT FOR RACING VEHICLES, WHICH MAY NEVER BE USED UPON A HIGHWAY AND ARE NOT INTENDED OR APPLICABLE FOR HIGHWAY USE.

**12104-3901FLT**

**Date: 7-22-11**