

ATTENTION!

Part Numbers: 502-20S & 501-12

Your system may contain a new style fuel pump that is not compatible with the fuel pump connector on the main wiring harness. If this is the case, cut off the connector on the main harness and use the ring terminals supplied with the fuel pump.

The following is the correct wiring:

Red Wire – Positive (+) terminal on the fuel pump

Green Wire – Negative (-) terminal on the fuel pump.

199R10287

Date: 5-2-02

ATTENTION!

Part Numbers: 502-20S & 501-12

Your system may contain a new style fuel pump that is not compatible with the fuel pump connector on the main wiring harness. If this is the case, cut off the connector on the main harness and use the ring terminals supplied with the fuel pump.

The following is the correct wiring:

Red Wire – Positive (+) terminal on the fuel pump

Green Wire – Negative (-) terminal on the fuel pump.

199R10287

Date: 5-2-02